

Drilling Options

Step by step instructions on how to drill the holes in a bowling ball

- Option #1 - Drilling the finger holes first
- Option #2 - Drilling the thumb hole first

Option #1 – Drilling the finger holes first

- 1) Draw centre line and midline of grip
- 2) Dividing the span of the middle finger in half, draw the span line for the middle finger and ring fingers
- 3) Draw bridge lines

A close-up of a crossAI-generated content may be incorrect.

- 4) Select the correct drill bit for the middle finger and set the correct pitches
- 5) Align the drill bit so that the cutting edges are lined up to just touch the bridge line and span line
- 6) Drill middle finger hole
- 7) Repeat steps 4 – 6 for the ring finger
- 8) If the specs (measurements) call for finger inserts, bevel the edges of the holes slightly and install them now
- 9) Using a ruler that is accurate to at least 1/16", place it at the bottom centre of the middle finger hole
- 10) Refer to spec sheet for the middle finger span
- 11) Measure from the middle finger along the centre line and mark the exact span distance by drawing an arc
- 12) Repeat steps 10 & 11 for the ring finger

A circular object with a black and white designAI-generated conte

13) Select the correct drill bit for the thumb and set the correct pitches

14) Align the drill bit so that the centre of the drill bit is on the centre line and so the cutting edge of the bit will just touch the spot where the 2 arcs intersect

15) Drill the hole

A circular object with circles and linesAI-generated content may b

Option #2 - Drilling the thumb hole first

- 1) Draw center line and midline of grip
- 2) Dividing the span of the middle finger in half, draw the span line for the thumb hole

A white circle with black linesAI-generated content may be incorrect

- i) Select correct drill bit for the thumb hole
- ii) Set the correct pitches
- iii) Align the drill bit so that the tip of the bit is on the centerline and the front of the bit just touches the span line
- iv) Drill thumb hole

A circular object with a circle and a circleAI-generated content may be incorrect

- v) Using a span ruler accurate to 1/16", place the clip on the front edge of the thumb hole
- vi) Refer to the spec sheet for span measurements
- vii) If installing finger inserts, measure the thickness of the front edge of the insert and subtract that amount from the total span (Example: the total span is 4 1/2" and the insert is

3/16" then the edge to edge or cut span is 4 5/16")

A yellow circle with black circleAI-generated content may be incor

0) Measure from the front edge of the thumb hole to a point 1/2" to the left and 1/2" to the right of the centerline, and mark the span lines

1) Draw bridge lines (1/4" for fingertip w/inserts, 3/8" for conventional)

2) Select the correct drill bit and set the pitches for the middle finger

3) Align drill bit so that the edge of the drill bit is set to just touch the span line and the bridge line.

4) Drill hole for middle finger. 1 1/2" deep for fingertip w/inserts and 2 1/4" deep for conventional

5) Repeat steps 12 - 14 for the ring finger hole

A circular object with circles and linesAI-generated content may b

6) Bevel finger holes and install the inserts if necessary

Drilling oval holes

Many thumbs are not round, and drilling an oval hole can give those customers a more comfortable and more useful fit

A grey oval with black textAI-generated content may be incorrect

As an example, a customer's thumb is 7/8" from front to back but is 1" from side to side

- 1) Set the correct pitches for the pilot hole (first cut) of the oval
- 2) Select the starting bit (should be the same as the front to back measurement of the thumb)
- 3) Drill the pilot hole
- 4) Move the table according to the calculations that Spectre has given you and make the next cut
- 5) Continue the procedure until you have made the final cut and confirm the correct side to side measurement with a calipers

A grey circle with black linesAI-generated content may be incorrect

- 6) Make sure to follow the movements calculated by Spectre to assure the smoothest oval with the least amount of finishing work

Finishing work

Beveling

Beveling is a procedure that is very important in making sure that every ball for the same bowler feels the same. Different amount of bevel can make the span feel either longer or shorter, therefore it is important to practice for consistency

It is recommended that you use a brand new sanding disk with every ball you do. This will make it easier to be more consistent

Finger Inserts

Finger inserts must be glued into the ball by rule so that they will not fall out and they are flush with the surface of the ball. Good technicians should be able to glue the grips in effectively with only 3 or 4 drops of super glue placed properly

Thumb slugs and Interchangeable thumb inserts

The majority of higher level bowlers will use either a slug or an interchangeable thumb insert to give them a more consistent feel from one ball to another. When using a slug or an interchangeable insert, double check your math to make sure that you end up with the correct span after it is installed