

Contour

Contour Oval



Oval:

- 0 pitch in the grip
- No compensation needed

Contour Semi Cerise



Semi:

- 3/16" FORWARD pitch in the grip

- Compensate 3/16" REVERSE when drilling the hole in the ball to arrive at the ending desired pitch
- Example: Normal Flex (1/4" REVERSE) = Drill the hole 7/16" REVERSE because $7/16" - 3/16" = 1/4"$

Contour Lady Semi Cerise



Semi:

- 3/16" FORWARD pitch in the grip
- Compensate 3/16" REVERSE when drilling the hole in the ball to arrive at the ending desired pitch
- Example: Normal Flex (1/4" REVERSE) = Drill the hole 7/16" REVERSE because $7/16" - 3/16" = 1/4"$

Contour Super Soft



Powerlift:

- 1/4" FORWARD pitch in the grip
- Compensate 1/4" REVERSE when drilling the hole in the ball to arrive at the ending desired pitch
- Example: Normal Flex (1/4" REVERSE) = Drill the hole 1/2" REVERSE because $1/2" - 1/4" = 1/4"$

Contour Oval Nubs



Oval Nubs:

- 0 pitch in the grip
- No compensation needed

Revision #2

Created 14 February 2025 18:30:59 by Chris Esdon

Updated 14 February 2025 18:53:12 by Chris Esdon